



PRIOR TO COLLECTION

- Plan enough time to complete sampling; samples must be returned within **48 hours** of collection
- Ensure the Sample Kit has the following items per collection point:
 - Chain of Custody (COC) form(s)
 - Containers per sampling point (refer to COCs and table below)
 - barcode label per container
 - Cooler(s) for return shipping

SAMPLE REJECTION

Samples will be rejected (not analyzed) if any of the criteria below is met:

- forms are incomplete, illegible, or missing
- bottle(s) is not labeled to match sampling point
- bottle(s) is not on ice or at proper temperature
- sample is frozen
- air bubbles/ headspace in glass vials
- sample is not received within holding time
- sample is not received in the DEQ provided container
- damaged beyond usability
- not collected from approved sample site


SAMPLE COLLECTION

1. Allow water from tap to run for five minutes then reduce flow to slow, steady stream.
2. Fill the provided bottle(s) to the level shown in figure to the right. **DO NOT FLUSH OUT PRESERVATIVE***
3. Replace the cap and securely fasten. Do not over tighten; this could damage the bottle.
4. Vertically place bar code label on associated bottle. The barcode must match the Chain of Custody for each sampling site. If bar code is not provided, write PWSID#, date/time collected, and sample point on the bottle; not the lid.
5. Replace netted sleeve for shipment.
6. Immediately place all bottles/vials in provided cooler and fill with ice. Do not store samples in freezer as they may become damaged.
6. Complete the Chain of Custody.
7. If necessary, proceed to next collection site and repeat steps 1-7.
8. See back for "Sample Delivery" details.

EPA Method #	Container Type and Count	# of Trip Blanks
504.1	3 x 40 milliliter Clear Glass Vial	2
507**	3 x 1 Liter Amber Glass Bottle	0
508**	3 x 1 Liter Amber Glass Bottle	0
515.3	1 x 8oz (250ml) Amber Glass Bottle	0
531.2	1 x 60 milliliter Amber Glass Vial	0
547	1 x 60 milliliter Amber Glass Vial	1
608	3 x 1 Liter Amber Glass Bottle	0

**All containers have powder preservative in each. Do not rinse out.*

*** 507/508 may share containers when assigned by the Lab*



SOC

Synthetic Organic Chemicals

State Environmental Laboratory Services Oklahoma Department of Environmental Quality



Sampling Guide For The Collection Of Synthetic Organic Chemicals

SAMPLE DELIVERY

MAIL

Sign and date each Chain of Custody form before mailing. Place all completed forms in a Ziploc® bag or other waterproof container. Place forms in the provided cooler or shipping container with your sample(s) and ice (if applicable). If using a courier, i.e. FedEx, UPS, etc., address your label as the following;

Oklahoma Department of Environmental Quality
707 N. Robinson
Oklahoma City, OK 73102

PERSONAL DELIVERY

The person delivering samples will sign all Chain of Custody form(s) at the receiving window of the DEQ Sample Management Unit located through the door on the northeast corner of the building. Hours of operation at Monday – Friday 8:00 am to 4:30 pm except on state holidays.

For collection assistance or questions, scan the QR code to the right to view the SELS contact page.



**Need
Help?**

For questions about the analytical prices and fees, scan the QR code to the right, or visit the SEL's page of the DEQ's website at www.deq.state.ok.gov



Page 2 of 2



For further assistance or concerns, call 1-866-412-3057 or email us at selsd@deq.ok.gov

This publication is issued by the Oklahoma Department of Environmental Quality authorized by Scott A. Thompson, Executive Director. Copies have been prepared at a cost of \$0.106 each. Copies have been deposited with the publications clearinghouse of the Oklahoma Department of Libraries. (SELS\Lab Guide Files\SOC Sampling Guide.pptx 2/2018)

